

ANC/Active Sound Control Unit Removal and Installation


Removal

Removal

1. HandsFreeLink Control Unit - Remove

[Remove the HandsFreeLink control unit.](#)

2. ANC/Active Sound Control Unit - Remove




1. Remove the ANC/active sound control unit (A).
2. Disconnect the ANC/active sound control unit connector.

Installation

Installation

1. ANC/Active Sound Control Unit - Install



1. Connect the ANC/active sound control unit connector.
2. Install the ANC/active sound control unit (A).

2. HandsFreeLink Control Unit - Install

[Install the HandsFreeLink control unit.](#)